



Hot Shoe Slave Trigger

Converts hot shoe flash guns into a slave triggered flash. Small (1 x 1/2 x 3/4), lightweight (6/10 oz.), easy to carry. Omni-directional, sensitive to 25ft. Mounts on camera shoe, tripod, or light stand.




CSA576 Hot Shoe Slave Trigger



Hot Shoe to PC Adapter

Converts hot shoe of camera to PC socket. Allows use of non-hot shoe flash units. Fits into camera hot shoe. Provides shoe for flash on top. Samigon blister pack. Master: 10




CSA552 Hot Shoe to PC Adapter



PC to Hot Shoe Adapter

Provides hot shoe contact for non-hot shoe cameras that allow use of hot shoe flash units. Fits onto camera. Cord plugs into PC outlet of camera. Samigon blister pack. Master: 10.




CSA555 PC to Hot Shoe Adapter



Flash Cord on Drum

16ft. PC/PC (male-female) straight extension cord on a drum for easy use and storage. Drum has tripod socket on bottom and flash shoe on top. Made in Germany. Samigon blister pack. Master: 4.



CSA545 PC/PC Flash Cord on Drum



Multi-PC Terminal-3 Outlets

Enables synchronized firing of up to 3 flash units simultaneously. Insert male PC plug of Multi-Terminal into camera PC socket. Connect up to 3 flash units with PC cords. Made in Germany. Samigon blister pack. Master: 18.



CSA520 Multi-PC Terminal - 3 outlets

Maxwell AC/DC Electronic Flash

An extremely versatile flash unit combining:

- Dual voltage AC operation. 110V for U.S., 240V for European current.
- Hot shoe and PC synching.
- AC and DC operation. AC power cord included. Requires 2-AA batteries for DC use.
- Can be positioned vertically or horizontally

Perfect for travelers, copy work, small studios, and general all-purpose flash photography

Guide No.: 70 (ASA100)

Dimensions: 1 1/4" x 4 1/8" x 2 1/2"

Weight: 5 1/2 oz.

Recycling Time: 5 -10 sec.

Includes: AC power cord, PC cord, and Built-in exposure calculator.




CSA315 AC/DC Electronic Flash

THE SHELL

An innovative attachment for on-camera flash units


It eliminates the problem of harsh and elongated shadows when moving from a horizontal to a vertical format.

The shape and positioning of THE SHELL keeps the light coming from above and slightly to the side of the lens in both horizontal and vertical positions – the most flattering light for portraiture.



"After four months of using the Shell in a variety of situations, I give it a Thumb's Up!"

Steve Sint, Popular Photography



Five flash head positions are available using THE SHELL. Each position gives a slightly different quality of light.

NOTE: The Shell can only be used with a flash unit that has a bounce and swivel head in order to properly position The Shell as shown.

Compatible Flashes: **ACHIEVER** 630AF, 632LCD. **CANON** 430EZ, 540EZ. **CONTAX** TLA360. **METZ** 40M Z-2. **MINOLTA** 5400HS. **NIKON** SB24, SB25, SB26. **NISSIN** 360TW. **NISTAR** AZ300 ZOOM, TZ320 TWIN ZOOM. **OLYMPUS** G40. **PHOENIX** ZIF105N. **PENTAX** AF500FTZ. **QUANTUM** Q FLASH QFT. **SIGMA** 430. **SUNPAK** 383 SUPER, 433AF, 544. **VIVITAR** 636AF, and others.

THE SHELL TSM is the same as THE SHELL but with a larger head to fit Metz CT45, CT60, Sunpack and Norman Professional Strobes.

CCH101 THE SHELL TSS

CCH105 THE SHELL TSM

FOR FAST DELIVERY CALL TOLL FREE!

EAST
1-888-ARGRAPH
OR 1-800-526-6290

WEST
1-888-WESTARG
OR 1-800-323-9069